

HOW TO ADJUST THE CHEMICAL DISPENSER SETTINGS

Cómo ajustar la configuración del dispensador químico

Comment régler les paramètres de distribution de produits chimiques

STEP 1: ENTER CHEMICAL MENU ♦ ENTER MENÚ QUÍMICO ♦ ENTRER MENU CHIMIQUE

  = 5 sec
PRESS BUTTONS SIMULTANEOUSLY

STEP 2: DETERGENT—INITIAL FILL ♦ DETERGENTE—LLENADO INICIAL ♦ DÉTERGENT — REMPLISSAGE INITIAL

DEFAULT = 50 sec

 = 

STEP 3: RINSE AID—INITIAL FILL ♦ ABRILLANTADOR—LLENADO INICIAL ♦ PRODUIT DE RINÇAGE—REMP LISSAGE INITIAL

DEFAULT = 10 sec

 = 

STEP 4: DETERGENT DOSAGE—WASH CYCLE ♦ DOSIFICACION DE DETERGENTE—CICLO DE LAVADO ♦ DOSAGE DE DETERGENT—CYCLE DE LAVAGE

DEFAULT = 8 sec

 = 

























STEP 5: RINSE AID DOSAGE—RINSE CYCLE ♦ DOSIFICACIÓN DE AYUDAS—CICLO DE ENJUAGUE ♦ RINÇAGE DOSAGE—CYCLE DE RINÇAGE











DEFAULT = 4 sec

 = 

STEP 6: EXIT PROGRAMMING MODE ♦ SALIR DEL MODO DE PROGRAMACIÓN ♦ QUITTER LE MODE DE PROGRAMMATION

DEFAULT = RCD

QUESTIONS? NEED ASSISTANCE?

¿PREGUNTAS? ¿NECESITA AYUDA?

DES QUESTIONS? BESOIN D'ASSISTANCE?

 **insinger**

800-344-4802